

CLOCKODILE

ČESKY

NÁVOD K HODINKÁM CLOCKODILE:

Jak nastavit čas: Pokud je pod korunkou plastová pojistka, vyjměte ji před nařizováním času. Povytláhněte korunku ve chvíli, kdy je vteřinová ručička v pozici 12 hodin. Otáčením korunky ve směru hodinových ručiček nastavte požadovaný čas. Poté korunku zatlačte zpět do základní pozice a ručičky se znovu rozběhnou.

POLSKI

Instrukcja zegarka CLOCKODILE:

Nastawianie czasu: W chwili gdy wskazówka sekundowa jest na godzinie 12, należy wysunąć koronkę i obracając ją w kierunku ruchu wskazówek zegara nastawić żądany czas. Wciśnięcie koronki kończy nastawianie.

DEUTSCH

Bedienungsanleitung für die Armbanduhr CLOCKODILE:

Zeiteinstellung: Sobald der Sekundenzeiger in der Position 12 Uhr ist, ziehen Sie die Krone. Dann drehen Sie die Krone im Uhrzeigersinn und stellen Sie die gewünschte Zeit ein. Dann drücken Sie die Krone wieder in die normale Position.

ENGLISH

INSTRUCTION MANUAL CLOCKODILE:

How to Set Time: If there is a plastic block underneath the crown, please take it out before setting the time. Pull the crown once the second hand has come in the 12-hour position. You set the time by turning the crown clockwise. Push the crown back to the basic position afterwards and the hands start moving again.

